

ADA MOTOR LTD	MAIN BEARING	LISTER / PETTER
----------------------	---------------------	------------------------

DESCRIPTION	ENGINE TYPE	SIZE	ADA MOTOR NUMBER	REFERENCE NUMBER
MAIN BEARING	LR / LD / SL	STD 0.25 0.50 0.75 1.00	47 4824 47 4825 47 4826 47 4824-030 47 4824-040	201-10063
CENTRAL BEARING	LR / LD / SL	STD 0.25 0.50 0.75 1.00	47 4827 47 4828 47 4829 47 4827-030 47 4827-040	570-12190
MAIN BEARING (Gear End)	LT / LV	STD 0.25 0.50 0.75 1.00	47 4830 47 4831 47 4832 47 4830-030 47 4830-040	601-30060
MAIN BEARING (Flywheel End)	LT / LV	STD 0.25 0.50 0.75 1.00	47 4833 47 4834 47 4835 47 4833-030 47 4833-040	601-30061
CENTRAL BEARING	LT / LV	STD 0.25 0.50 0.75 1.00	47 4836 47 4837 47 4838 47 4836-030 47 4836-040	602-36270
MAIN BEARING (Gear End)	LPW	STD 0.25 0.50 0.75 1.00	47 4869 47 4869-010 47 4869-020 47 4869-030 47 4869-040	750-11240
MAIN BEARING (Flywheel End)	LPW	STD 0.25 0.50 0.75 1.00	47 4870 47 4870-010 47 4870-020 47 4870-030 47 4870-040	750-11210

ADA MOTOR LTD	MAIN BEARING	LISTER / PETTER
----------------------	---------------------	------------------------

DESCRIPTION	ENGINE TYPE	SIZE	ADA MOTOR NUMBER	REFERENCE NUMBER
CENTRAL BEARING	LPW	STD 0.25 0.50 0.75 1.00	47 4871 47 4871-010 47 4871-020 47 4871-030 47 4871-040	750-11250
MAIN BEARING	SR / SRW	STD 0.25 0.50 0.75 1.00	47 4853 47 4853-010 47 4853-020 47 4853-030 47 4853-040	201-50060
MAIN BEARING	SR4	STD 0.25 0.50 0.75 1.00	47 4854 47 4854-010 47 4854-020 47 4854-030 47 4854-040	570-12160
CENTRAL BEARING	SR / SRW	STD 0.25 0.50 0.75 1.00	47 4855 47 4855-010 47 4855-020 47 4855-030 47 4855-040	570-11171
MAIN BEARING	ST / STW	STD 0.25 0.50 0.75 1.00	47 4840 47 4841 47 4842 47 4840-030 47 4840-040	570-12970
CENTRAL BEARING	ST / STW TS / TR / TL / TX	STD 0.25 0.50 0.75 1.00	47 4843 47 4844 47 4845 47 4843-030 47 4843-040	570-12990
MAIN BEARING (Gear End)	TS / TR / TL / TX	STD 0.25 0.50 0.75 1.00	47 4846 47 4847 47 4848 47 4846-030 47 4846-040	570-30010

ADA MOTOR LTD	MAIN BEARING	LISTER / PETTER
----------------------	---------------------	------------------------

DESCRIPTION	ENGINE TYPE	SIZE	ADA MOTOR NUMBER	REFERENCE NUMBER
MAIN BEARING (Flywheel End)	TS / TR / TL / TX	STD 0.25 0.50 0.75 1.00	47 4849 47 4850 47 4851 47 4849-030 47 4849-040	570-30011
MAIN BEARING	HA / HB / HW	STD 0.25 0.50 0.75 1.00	47 4859 47 4860 47 4861 47 4859-030 47 4859-040	351-10060
CENTRAL BEARING	HA / HB / HW	STD 0.25 0.50 0.75 1.00	47 4856 47 4857 47 4858 47 4856-030 47 4856-040	352-12671
MAIN BEARING	HR / HRS / HRW / HRWS / HL / HLT	STD 0.25 0.50 0.75 1.00	47 4862 47 4863 47 4864 47 4862-030 47 4862-040	352-50620
CENTRAL BEARING	HR / HRS / HRW / HRWS / HL / HLT	STD 0.25 0.50 0.75 1.00	47 4865 47 4866 47 4867 47 4865-030 47 4865-040	351-50260
MAIN BEARING	AV1 / AV2	STD 0.25 0.50	47 6513 47 6514 47 6515	390143
CENTRAL BEARING	AV1 / AV2	STD 0.25 0.50	47 6516 47 6517 47 6518	393016

ADA MOTOR LTD	MAIN BEARING	LISTER / PETTER
----------------------	---------------------	------------------------

DESCRIPTION	ENGINE TYPE	SIZE	ADA MOTOR NUMBER	REFERENCE NUMBER
MAIN BEARING (Flywheel End)	PJ / PJW	STD	47 6522	264907
		0.25	47 6523	265490
		0.50	47 6524	265491
MAIN BEARING (Flywheel End)	PH / PHW	STD	47 6525	264905
		0.25	47 6526	268296
		0.50	47 6527	268297
MAIN BEARING (Gear End)	PH / PHW / PJ / PJW	STD	47 6530	264904
		0.25	47 6531	265481
		0.50	47 6532	265482
CENTRAL BEARING	PH / PHW / PJ / PJW	STD	47 6534	392994
		0.25	47 6535	392995
		0.50	47 6536	392996